

## Audi A8 Security Code Options for Concert Stero

Code	Binary (2Ex)	Function				Horn honk				Remote Window	Auto Lock	Safety Lock	One Touch	Description			
		14	13	12	11	10	9	8	7	6	5	4	3		2	1	0
Decimal		16392	8196	4096	2048	1024	512	256	128	64	32	16	8	4	2	0	
<b>16140</b>		0	1	1	1	1	1	1	0	0	0	0	1	0	0	0	Safety Lock, Horn Honk
<b>15176</b>		0	1	1	1	0	1	1	0	1	0	0	0	1	0	0	One Touch Lock, Remote Window Control, No Horn Honk
<b>16200</b>		0	1	1	1	1	1	1	0	1	0	0	0	1	0	0	One Touch Lock, Remote Window Control, Horn Honk
<b>16204</b>		0	1	1	1	1	1	1	0	1	0	0	1	0	0	0	Safety Lock, Remote Window Control, Horn Honk
<b>15180</b>		0	1	1	1	0	1	1	0	1	0	0	1	0	0	0	Safety Lock, Remote Window Control, No Horn Honk
<b>15208</b>		0	1	1	1	0	1	1	0	1	1	0	0	1	0	0	One Touch Lock, Auto Lock, Remote Window Control, No Horn Honk

**Apparent Rules:**

Safety Lock and One Touch are mutually exclusive
--

**Notes:**

Bold codes/functions have been tested
Safety Lock - 1st command: driver unlock, 2nd command rest unlock
One Touch - 1st command all unlock
Auto Lock - doors lock once vehicle exceeds xMPH
Remote Window - Hold remote. After 2-5 sec, windows open/close